

## SELFIE READY RESCUE PRIMER

**Formulation** 

**Product Category:** Skin Care **Formulation Code:** SG 4-132

| INCI Name/Chemical Name   | Trade Name                               | Supplier                        | Percentage (%) |
|---|--|---------------------------------|----------------|
| Phase A   |  |                                 |                |
| Water   | Water                                    |                                 | 73.90          |
| Glutamic Acid N,N-Diacetic Acid, Tetra Sodium<br>Salt                   | Dissolvine®GL-47-S                       | Akzo Nobel                      | 0.10           |
| Ammonium Acryloyldimethyltaurate/VP Copolymer                           | Aristoflex® AVC                          | Clariant                        | 1.00           |
| Glycerin  | Glycerin 99.7% Natural USP               | Bruchem Inc.                    | 3.00           |
| Phase B   |  |                                 |                |
| Glyceryl Stearate, Cetearyl Alcohol,<br>Sodium Stearoyl Lactylate       | Biobase S                                | TRI-K Industries, Inc.          | 3.00           |
| Caprylic/Capric Triglyceride  | Jeechem® CTG                             | Jeen® International Corporation | 2.00           |
| Squalane  | OleaClear Olive Squalane                 | TRI-K Industries, Inc.          | 3.00           |
| C12-15 Alkyl Benzoate   | Finsolv® TN                              | Innospec Performance Chemicals  | 3.00           |
| Theobroma Cacao (Cocoa) Seed Butter                                     | Tomasa Cocoa Butter                      | TRI-K Industries, Inc.          | 2.00           |
| Hydrogenated Ethylhexyl Olivate, Hydrogenated Olive Oil Unsaponifiables | Fision® EcoSil                           | TRI-K Industries, Inc           | 2.00           |
| Tocopheryl Acetate  | Vitamin E Acetate                        | TRI-K Industries, Inc.          | 0.50           |
| Phase C   |  |                                 |                |
| Phenoxyethanol, Capryloyl Glycine, Undecylenoyl Glycine                 | Galgard Trident                          | TRI-K Industries, Inc.          | 1.00           |
| Phase D   |  |                                 |                |
| Water Hydrolyzed Soy Protein, Acacia Senegal<br>Gum, Xanthan Gum        | Fision® Instant Lift                     | TRI-K Industries, Inc           | 2.00           |
| Hydrolyzed Hemp Seed Extract (pending)                                  | Hemp Tein Z NPNF®                        | TRI-K Industries, Inc.          | 2.00           |
| Mica, Titanium Dioxide  | Timica® Soft Luster White<br>6500        | BASF                            | 1.00           |
| Boron Nitride   | Softouch* CC6058 Boron<br>Nitride Powder | Essential Ingredients           | 0.50           |

## **Procedure:**

- 1. Add all ingredients of Phase A to water one at a time until fully hydrated and uniform. Heat to 75°C.
- 2. Combine and heat Phase B to 75°C.
- 3. Add Phase B to Phase A at  $75^{\circ}$ C, and homogenize for 3 minutes.
- 4. Switch to propeller mixing, start cooling the batch to 40°C.
- 5. Add Phase D ingredients one at a time, mix to uniformity.
- 6. Cool batch to 30°C.

The information presented herein is provided in good faith and is believed to be accurate and reliable based on our current knowledge. No legally binding promise or warranty is made regarding the suitability of our products for any specific use. TRI-K Industries, Inc. will not assume any expressed or implied liability in connection with any use of this information.

TRI-K Industries, Inc.

Specialties Division

2 Stewart Court, P.O. Box 10

Denville, NJ 07834, USA

t (973) 298-8850 f (973) 298-8940

info@tri-k.com • www.tri-k.com

TRI-K Industries, Inc.
Proteins Division
8 Willow Street #2
Salem, NH 03079, USA
t (603) 898-0811 f (603) 898-0816
info@tri-k.com • www.tri-k.com